










Cod.	Modello	Tipo	Funzione	Listino IVA inclusa cad.	Prezzo Speciale Sconto 20%	
05088	INPUTSWITCH	Adattatore ingresso	Per collegare 3 ingressi linea o phono, ad un unico ingresso phono nell'amplificatore	€ 51,00	€ 40,80	<p>Inputswitch</p> <p>DEqualised 3-way input for CD, Video, satellite TV and Record Deck into the Record Deck input, for use where no AUX, Tape or Line input is available. Order code: IS-17N</p>
05089	SYSTEMSWITCH	Selettore audio	Per controllare e registrare varie sorgenti audio e video nell'impianto	€ 51,00	€ 40,80	<p>Systemswitch</p> <p>Play and record integration allowing any record-play combination for HiFi, NICAM TV/Video, and Satellite sound with a HiFi/audio system. Order code: SY-22N</p>
05090	VIDEOSWITCH	Selettore A/V	Per monitorare/collegare 3 sorgenti video BNC su un TV	€ 51,00	€ 40,80	<p>Videoswitch</p> <p>AV select and routing for Video camera monitor AV systems (3-way in or out switching). Connections: BNC (Video), Phono (Audio) Order code: VS-04N</p>
05091	TELESWITCH	Selettore A/V	Per monitorare/collegare 3 sorgenti video RF su un TV	€ 51,00	€ 40,80	<p>Teleswitch</p> <p>RF switching for aerials, TV, Video, Computers, etc. (3-way in or out switching). Order code: TS-02N</p>
05092	VOLUMESWITCH	Controllo volume	Per regolare volume e on/off di diffusori aggiuntivi / remoti	€ 51,00	€ 40,80	<p>Volumeswitch</p> <p>An in line volume control for extension speakers, including on-off switch. Can be used with all parallel speaker switches. Order code: VO-13</p>
05093	PHONOAMP	Pre Phono	Per collegare un giradischi ad ingresso linea/aux di amplificatore, equalizzazione RIAA, ingresso testina MM	€ 64,00	€ 51,20	<p>Phonoamp</p> <p>PU RIAA magnetic pre-amp providing record deck input for AUX, Tape or Line in. Order code: PA-12</p>
05096	MICAMP	Pre Microfono	Per collegare 1 o 2 microfoni mono/stereo ad ingresso linea/aux di amplificatore	€ 64,00	€ 51,20	<p>Micamp</p> <p>Microphone pre-amp enabling mono or stereo microphones to be connected into AUX, Tape or Line in. Order code: MA-09</p>
05097	LINEAMP	Booster segnale	Per amplificare un segnale di linea stereo su connessioni lunghe	€ 64,00	€ 51,20	<p>Lineamp</p> <p>Audio line level booster providing stereo amplification with gain control for audio line distribution. Ideal for long run audio lines. Order Code: LA-28</p>

05099	RADIOAMP	Booster segnale	Per amplificare un segnale radio da antenna FM	€ 64,00	€ 51,20	<p>Radioamp An in line FM Radio signal booster. Improves stereo radio reception. Power supply: Mains adaptor, battery or 12V DC line. Order code: RA-10</p> 
05100	TELEAMP	Booster segnale	Per amplificare un segnale TV da antenna fino a 4 volte	€ 64,00	€ 51,20	<p>Teleamp An in line TV signal booster. Improves signal with a 4 times increase. Power supply: Mains adaptor, battery or 12V DC line. Order code: TA-11</p> 
05101	ATTENUATOR	Attenuatore	Per regolare il volume di un ingresso linea separatamente	€ 47,00	€ 37,60	<p>Attenuator Audio attenuator providing adjustment for equipment with differing In or Out levels. (e.g. between equipment from different manufacturers). Order code: AT-07</p> 
05102	D-EQUALISER	Adattatore ingresso	Per collegare una sorgente linea ad un ingresso phono nell'ampli	€ 42,00	€ 33,60	<p>D-Equaliser EQ Adaptor converting the record deck input, for connection of CD, Tape, DCC, Satellite, Video or Line In into a Phono (Record Deck) input. Order code: EQ-27</p> 
05106	SUPERLOOP	Antenna TV amplificata	Per ricevere e amplificare fino a 4 volte il segnale TV	€ 55,00	€ 44,00	<p>Powerscan Superloop An active power boosted TV aerial raising any captured signal by 4 times. Power supply: Mains adaptor, battery or 12/24 DC line. Order code: PS-TV</p> 
05107	SUPEROD	Antenna FM amplificata	Per ricevere e amplificare il segnale radio	€ 65,00	€ 52,00	<p>Powerscan Superrod An active power boosted FM radio aerial. Power supply: Mains adaptor, battery or 12/24 DC line. Order code: PS-FM</p> 
05113	TAPE 3	Selettore audio	Per collegare tre unità di registrazione con duplicazione fra loro	€ 124,00	€ 99,20	<p>TAPE THREE - PG-T3 <input type="checkbox"/> TAPE DECKS: Providing for three tape record/play units. <input type="checkbox"/> PLAY: Play back from any deck. <input type="checkbox"/> RECORDING: On to any deck from any source. <input type="checkbox"/> DUBBING: Recording from any deck to any decks. <input type="checkbox"/> SIMULTANEOUS: Recording all decks. <input type="checkbox"/> PLAY/MONITOR: Play/monitor any deck while cross recording any two.</p> 
05115	SPEAKER 3	Selettore audio	Per collegare e controllare 1 coppia di diffusori principali e 2 coppie remote; presa per cuffia; carico max 130W RMS;	€ 106,00	€ 84,80	<p>SPEAKER THREE - PG-S3 <input type="checkbox"/> SPEAKERS: Providing for main and two remote pairs. <input type="checkbox"/> CONTROL: On or off in any combination. <input type="checkbox"/> HEADPHONES: Provision for one pair of headphones. <input type="checkbox"/> CONNECTION: By heavy duty gold posts. <input type="checkbox"/> CABLE: Heavy duty connection, also banana plugs, spades or lugs.</p> 
05116	SPEAKER 4	Selettore audio	Per collegare e controllare 1 coppia di diffusori principali e 3 coppie remote; presa per cuffia; carico max 130W RMS;	€ 196,00	€ 156,80	<p>SPEAKER FOUR - PG-S4 <input type="checkbox"/> SPEAKERS: Providing for main and three remote pairs. <input type="checkbox"/> CONTROL: On or off in any combination. <input type="checkbox"/> CONNECTION: By heavy duty gold posts. <input type="checkbox"/> CABLE: Heavy duty connection, also banana plugs, spades or lugs. <input type="checkbox"/> LOADING: Safe amplifier load, regardless of combination.</p> 
05123	SPEAKER 4 GOLD	Selettore audio	Come Speaker 4, connettori dorati	€ 212,00	€ 169,60	